

Registering your switch-accessible Software in USBKeys2 Mac


1. If you have a Crick USB Switch Box, plug it in (you do not need a box to register your software titles).

Install the USBKeys2 software and run the application.




2. Open the application you wish to register.


3. Click on the USBKeys2 icon in the menu bar and click *Remember New Application*. Click *Next* to display a list of open applications.



4. Select your application from the list and click *Next*.



5. USBKeys2 should gather information about the application and publisher that you may wish to change. Click *Next* to continue.




6. USBKeys2 will populate this field automatically. This text is used to identify your application, so please ensure that this text always appears in the title of the window (usually the name of the application). If there is no text that always appears, uncheck the box .

Click *Next* to continue.




7. Setup an action for each switch.

- a) Use the corresponding buttons to setup the action for each switch.
- b) Choose the key press or mouse click your application responds to and click *OK*.




8. Here, you can add notes on how to setup switch access, alternative setups, describe switch actions and add any other relevant information. Click *Next*.


Click *Finish* to complete the registration. You will need to repeat steps 2 to 8 for all your switch-accessible applications.



9. If you want to edit any information, click on the USBKeys2 icon in the menu bar and click *Edit Applications*.



10. When you've registered all of your applications, click on the USBKeys2 icon in the menu bar and click *Export Database*.



Please save the database and email it to support@cricksoft.com.